







## Photo Instructions











































































Circled gear (with tan connector) isn't used and can be removed.







Important: Fold up sides, skis folded in, base plate up, and 2 half beam in this position





Circled part hasn't been completed yet































Circled gear has no connector. Insert 6 axle if it keeps slipping out.














Circled gear isn't used and can be removed




Important: Skis folded in and 3 Half Beam in this position










These parts don't connect to anything yet.



























































Finished!

